

Standalone AVR Chip Prep w/ Arduino Bootloader

AVR Chips on the arduino uno come loaded with a bootloader to run the usb communication & arduino stdlib. This is how to go from a blank chip to a flashed chip.

Chip Initial Prep

Pin connections:

```
16MHz Crystal across PB6/PB7
connect 22pF bipolar caps from the crystal to ground:
```

```

                                GND
PB6 -----|-----[22pF]--|
           [Crystal]         |
PB7 -----|-----[22pF]--|
```

```
Pin R10k pullup to +5V
AVCC connected to +5V
also might be useful to have pwr indicator LED
```

Arduino as ISP Setup & Burning

- Start by Loading File → Examples → 11.ArduinoISP → ArduinoISP
- Connect seperate Arduino UNO board (hereafter called the programmer) to pc via usb.
- Upload the ISP sketch to the programmer.
- Install the [MiniCore library](#) and install the MiniCore boards
- Wire the following connections from the programmer:

```
10 -> MOSI (17)
11 -> MISO (18)
12 -> SCK (19)
13 -> RESET (1)
```


From:

<https://memex.kyaruc.moe/> - **kyaruc memex**

Permanent link:

<https://memex.kyaruc.moe/misc:avr-programming?rev=1773942293>

Last update: **2026-03-19 Thu 17:44**

