

3D Printing Stuff

knowledge → vomit → wiki

Esteps Calib

- Load Filament (bright color recommended)
- Find out M92 E esteps with M503
- From base of extruder, mark point at 120mm/12cm
- Set local coords and extrude 100mm@1mm/s

```
M83          ; E relative mode
G1 E100 F60 ; Extrude 100mm @ 1mm/s (60mm/min)
```

- When extrusion finished, measure from base to mark.
- Calculate new esteps using previous measurement x : $E_{\text{new}} = E_{\text{orig}} \cdot \frac{100}{120-x}$
- Set new value with M92 (ie. M92 E421).

X/Y Offset (Marlin)

```
G28          ; home
G0 X[x offset] Y[y offset] ; move to proper bed origin
M428        ; set current pos as bed origin
M500        ; write to EEPROM
```

From:
<https://memex.kyaruc.moe/> - **kyaruc memex**

Permanent link:
<https://memex.kyaruc.moe/3dp?rev=1778210445>

Last update: **2026-05-08 Fri 03:20**

